



Materials and Processing Technology Area


Institute for **ADVANCED**
Composites Manufacturing
INNOVATION

Cliff Eberle
Director,
Materials and Processing TA

January 13, 2016

Materials and Process Technology Area Snapshot

Carbon Fiber
Technology Facility



- Carbon fibers
- Lab-scale intermediates and composites prototyping
- Recycling
- Nondestructive evaluation (NDE)
- Materials characterization



CO

- Thermo-plastic-glass-carbon recycling
- Factory floor NDE
- Full-scale molding with LCCF
- Pultruded spar caps

IN

- Product lifecycle modeling
- Process modeling for lab-scale validation

KY

- Largest open access solution spinning lab in US



MI


- Closed loop recycling
- Factory floor NDE
- Full-scale preforming
- Molding processes with LCCF

OH

- Factory floor NDE
- Full-scale preforming and winding processes with LCCF

Integration is Critical

- M&P liaisons assigned to lead integration with other Technology Areas
- M&P leaders responsible for seamless integration within M&P Technology Area



M&P Technology Area mission is to enable technology deployment through Application Technology Areas

Materials and Processing POC's



Doug Adams (NDE)
douglas.adams@vanderbilt.edu
615-322.-2697



Cliff Eberle (M&P)
eberlecc@ornl.gov
865-574-0302



Soydan Ozcan (Recycling)
ozcans@ornl.gov
865-241-2158



Dayakar Penumadu
Materials characterization
dpenumad@utk.edu
865-974-2503



Uday Vaidya (CTO)
uvaidya@utk.edu
205-410-2898



Matt Weisenberger
Solution Spinning
matt.weisenberger@uky.edu
859-257-0322



Innovations in NDE for Composites Manufacturing

Institute for **ADVANCED**
Composites Manufacturing
INNOVATION

Doug Adams
Tech Fellow in NDE,
Daniel F. Flowers Professor,
Vanderbilt University


January 13, 2016

What is NDE?

To see what is unseen!



Is this polymer uniform?





Material (% wt.)	Control	Test 2
LiCoO ₂	96	96
PVDF	2	1
Carbon Black	2	3


Sharp, N., Adams, D., and Caruthers, J., "Lithium-Ion Battery Electrode Inspection using Pulse Thermography," 2014, NDT&D International, Vol. 64, pp. 41-51.

Full-Field Imaging to Diagnosis the Composite Material State In-Line


- In < 0.5 second, we can detect variations in both chemistry and geometrical flaws for use in adjusting process controls.




NDE Sensors Now in Reach for Wide Scale Deployment



Innovation



Use nonlinearity to overcome barrier to inspecting large complex structures



NDE
Path to
Innovation

Implementation




Industry Need

Inaccessible bond line
Advanced joining concepts



Bond, R., Underwood, S., Cummins, J., and Adams, D. E., "Structural Health Monitoring-Based Methodologies for Managing Uncertainty in Aircraft Structural Life Assessment," *Structural Health Monitoring*, October 9, 2014, doi: 10.1177/1475921714553733.


The Cost of Composite Part Variation



Question

What price will you pay for this batch of parts?


Combine Modeling & Simulation with NDE & Characterization for Decision Making to Enable Speed and Quality



Source Renishaw plc, New Mills, Wotton-under-Edge, Gloucestershire GL12 8JR, U.K.


Case Study Showing Benefits for Metals Machining Process

Process setting only




$C_{pk} = 0.32$
 $P_{pk} = 0.39$
Scrap/rework = 12.1%

Process setting & post-process monitoring



$C_{pk} = 0.81$
 $P_{pk} = 0.86$
Scrap/rework = 0.5%

Process setting & in-process control




$C_{pk} = 1.66$
 $P_{pk} = 1.55$
Scrap/rework = 0.0002%

60,000 times less scrap and rework!

Source: Renishaw plc, New Mills, Wotton-under-Edge, Gloucestershire GL12 8JR, U.K.


Vision for NDE in Composites Manufacturing

- In cost and energy efficient high-volume manufacture of composites, NDE can:
 - Diagnose the material state in-line to support process decisions in order to reach speed & quality targets.
 - Characterize the material state to support simulation in order to innovate and improve upon process.




What it means in practice: e.g. NDE in-line diagnostics

- Processes are dynamic.
- NDE methods rely on dynamic signatures.
- So, we will use process dynamics for NDE!




Mobile NDE Lab at Oak Ridge National Lab Carbon Fiber Technology Facility

Precursor tow band exhibits fuzz which is observed with two 2D laser profilometers to render 3D tow form




12 tows total of 24k precursor (4 tows shown)

Setup of Real-Time, Non-Contact, Profilometry NDE System at CFTF




2D laser specs: Z Range: +/- 48 mm, X Beam Width: 62 mm, Sample Rate (max.) : 62500 Samples/sec. , Resolution: X: 100 μ m, Z: 1 μ m

Profile along Tow for In-Line Fuzz Detection of Precursor





Combining the 2D data through time after correlating top and bottom lasers, we can create a 3D profile.


Statistical Analysis of Carbon Fiber Tow Form - Width Distributions



Tow #1
Wider distribution




Tow #3
Skewed distribution



Tow Dynamics for In-Line Diagnostics of Carbon Fiber Properties

- Oscillations of tow are a “fingerprint” with which to diagnose state of fiber


$$m\ddot{x} + kx = f(t)$$



Excite the machinery or tow fibers to make a coherent measurement

Change in Linear Density Detected in Carbon Fiber using Resonance

- Droplet: 0.036 grams; Tow: 0.461 grams




$$f = \frac{n}{2L} \sqrt{\frac{T}{\rho}}$$

Similar Ideas for In-Line NDE of Material State for Composite Manufacturing

- Composites manufacturing relies on uniform flow, cure, etc.
- Variations occur in the process due to material batch and the environment, e.g., humidity.
- Improve process speed and quality using in-line NDE.



Courtesy: Wind Turbines Tech Area
Derek Berry, NREL




Infrared imaging to monitor full-field temperature of two-part epoxy as it reaches full cure

The Institute for Advanced Composites Manufacturing Innovation

What it means in practice: e.g. NDE to Support Simulation



- Processes are simulated to account for multi-physics effects on material state.
- In-process and post-process NDE can estimate material state.
- So, we will use NDE to inform simulation to close the loop around simulation models.



Courtesy: Design, Modeling and Simulation Tech Area
R. Byron Pipes, Purdue University

NDE Overview

- Use NDE data to help meet IACMI metrics for speed and quality by closing the loop around process design and control.
- Deploy technology across supply chain through a mobile NDE lab.



Acknowledgements of Our Team



David Koester
Research Scientist



Janette Meyer
Post doc scholar



Garrett Thome
Research Engineer



Raymond Bond
Research Engineer



Cliff Eberle, ORNL
Composite Materials
and Process Director



Soydan Ozcan, ORNL
Recycling



Matt Weisenberger, UKY
Solution Spinning



Dayakar Penumadu,
UTK
Materials
characterization



R. Byron Pipes, Purdue
Design, Modeling and
Simulation Director



Derek Berry, NREL
Wind Turbines
Director

The Institute for Advanced Composites Manufacturing Innovation

Acknowledgements of Our Team



**Carbon Fiber Technology Facility Staff
Oak Ridge National Laboratory**



Innovations in NDE for Composites Manufacturing

Institute for **ADVANCED**
Composites Manufacturing
INNOVATION

Doug Adams
Tech Fellow in NDE,
Daniel F. Flowers Professor,
Vanderbilt University

January 13, 2016